

Surtronic[®] Duo



Portable surface roughness testers



What it does

The Surtronic Duo is superior portable surface roughness tester that measure multiple roughness parameters with a 1-button click. Roughness measurement parameters such as Ra, Rz, Rp, Rv and Rt are displayed on a brightly lit intuitive 2.4" LCD colour display. Its rechargeable battery operation makes it a convenient way of performing fast, easy and precise on-the-spot measurements in almost any environment and surface.

How it does it

The hard-wearing diamond stylus is drawn across the part with a precision motorised traverse mechanism to ensure that the correct horizontal distance is travelled. Vertical movement of the stylus is detected by a high quality piezo-electric pick-up as it travels across peaks and valleys which converts mechanical movement into electrical signals. The electrical signal is digitised and sent to a microprocessor for instant calculation of surface parameters using standardised algorithms.



USB Mini charging

The mini USB port can be used for charging with the included mains charger (or with any standard USB charger).



Surtronic[®] Duo

Bluetooth technology

Quick, reliable communication between traverse and display/ control unit.

The add

Measure

Tactile measurement button great for challenging orientations

Separates

The Duo splits into a display/control unit and traverse unit via a slide and lock mechanism.

Diamond stylus and piezoelectric pick-up

The hard wearing, robust piezoelectric pick-up stylus with diamond tip assures very reliable measurement.

Li-Poly battery

Most advanced rechargeable battery technology for unrivalled reliability and battery life.

Profile graph

Clear detailed graph showing measurement area – excellent for visually identifying defects.



Simple 3-button navigation Instant access to menu options

Charge from mains or any standard USB charging port.

Rubberised moulding

Enhanced durability and improved grip provides unbeatable protection in harsh shop floor environments.

Keeping it simple

The Surtronic philosophy keeps the process simple. It is the perfect tool for any inspector to check surface roughness even in the most demanding applications.

- Incoming inspections
- Final inspection before shipment
- Process control on the production line
- Checking large components or structures

Standards and traceability

The reference standard supplied can be used both to calibrate the instrument and check for stylus wear to ensure the most accurate results are always being achieved.

Measurement	Best capability
Roughness standards (Ra)	±(2% + 0.004 μm)
Workpiece or component surface texture (Ra)	±3% of measured value per trace

UKAS calibration and testing

Taylor Hobson provides full certification for artefacts and instruments in our purpose built ISO graded clean room UKAS facility. Our UKAS laboratory is able to measure all of the parameters associated with surface texture, including French, German, USA and Japanese derivatives.





Tough, fast and reliable handheld roughness testers...

Durable roughness testers for shop floor, industrial & inspection room applications



Fast and reliable

Simply press the measurement button and in a few seconds a full set of traceable measurement results including a detailed profile graph is displayed.

Built to last, by design...

Impact resistant rubberised mouldings surround a recessed, Mylar protected high durability screen making the unit robust enough for even the most demanding industrial environments.

InstantOn

By utilising InstantOn technology these instruments are ready to measure in less than 5 seconds from switching on!

In situ measurements

Monitor wear and roughness changes in situ during product's life. E.g. monitoring changes in turbine blade roughness as an early warning sign for defects and efficiency losses.

User-friendly, not user-hostile!

The Surtronic Duo are as simple and easy-to-use as any SmartPhone. Users have the advantage of the intuitive quick access 3-button menu and its crisp 2.4" daylight readable industrial colour LCD screen

Bluetooth connectivity

This next generation bluetooth technology boasts super efficient connectivity allowing wireless communication between the display unit and traverse unit.

Built for power...

Powered by heavy duty reliable Li-Poly technology, the Surtronic Duo operates 24/7 with over 2000 measurements from a single charge.

Parameters available: ISO 4287 Roughness*

- Rt total profile height
- **Rp** maximum profile peak height
- Rv maximum profile valley depth
- Rz maximum height of the profile
- Ra arithmetic mean deviation

Other parameters include: Rsk, Rku, Rq, Rz1max * Includes primary parameters

Applications




















and many more ...


Process control	_	Grinding, turning, milling, honing, polishing, extrusion
Heavy industry	_	Shipbuilding, pipelines, sheet steel
Aerospace	_	Turbine blades, turbine shafts, wing composites
Other	_	Print rollers, flooring, bonding, glass

Technical specification

Instrument p	erformance	Surtronic [®] Duo		
Gauge	Resolution	0.01 µm (0.4 µin)		
Measurement Range (Ra) Range (Rz, Rv, Rp, Rt) Repeatability		Up to 40 µm (1600 µin)		
		Up to 199 µm (7800 µin)		
		2 % of value + noise		
	Accuracy	5 % of reading + 0.1 µm (4 µin)		
	Noise	0.1 µm (4 µin)		
Calibration	Process	Automatic software calibration		
	Standard	Able to calibrate to ISO 4287 Roughness Standards		
Parameters	Standards	ISO 4287		
	ISO 4287 (Roughness)	Ra, Rz, Rp, Rv, Rt, Rz1max, Rsk, Rq, Rku		
	ISO 4287 (Primary)	Pa, Pz, Pp, Pv, Pt		
Technical		Surtronic [®] Duo		
Data output	On-screen	Up to 5 results per page, selectable on-screen graph		
Battery		Mini USB 5V 1A 110-240 VAC 50 / 60 Hz		
Battery Charger Charging time		4 hours		
Power	Battery life	> 10,000 measurements per charge		
1 Ower	Standby time	5.000 Hours		
InstantOn		Max 5 sec from standby to ready to measure		
	Auto-sleep function	5 minutes		
Instrument c	apability	Surtronic [®] Duo		
Pick-up assembly	Pick-up type	Piezoelectric		
	Stylus type	Diamond, Radius 5 µm (200 µin)		
Gauge	Gauge force	200 mg		
	Measurement type	Skidded		
Filter	Filter type	Gaussian		
	Filter cut-off	0.8 mm		
Traverse	Traverse length	5 mm (0.2 in)		
	Traverse Speed	2 mm/sec (0.08 in/sec)		
Display	Units	μm / μin		

Environmenta	al/physical	Surtronic [®] Duo
Physical specifications	Weight including pickup	0.4 Kg (14 oz)
specifications	Power source	Li-Poly rechargable battery
Operating conditions	Temperature	5 - 40 °C (41 - 104 °F)
conditions	Humidity	0 - 80 % non-condensing
Storage conditions	Temperature	0 - 50 °C (32 - 122 °F)
	Humidity	0 - 80 % non-condensing

Surtronic[®] Duo dimensions



What is a skid?

Surtronic Duo is a skidded device. The skid guides the pick-up along the workpiece, with the workpiece itself forming the datum for measurement. This method usually eases set-up by reducing the need for leveling. It also reduces the effects of vibration due to a much smaller measuring loop.

The skid is an integral part of the gauge and has a radius large enough to prevent movement in and out the roughness characteristics of the surface. The stylus and the skid are independent in their height (Z) movement but move together in the measurement direction. Surface deviations are recorded as the difference between the stylus and the skid movement in the Z direction.


The skid will act as a mechanical filter, taking out much of the general form of the component. Also, wavelengths greater than the diameter of the skid will not register.

How much difference does the stylus tip size make?


These instruments use a 5 μ m (200 μ in) stylus tip radius. This suits their purpose as a portable tool for checking roughness in three ways:

- **Durability** It is less likely to be damaged even when subjected to mishandling.
- Maintenance It is easier to remove dirt and oil that collects on the tip during use.
- **Suitability** It acts as a filter to remove the highest surface frequencies that are more reliably measured in a controlled environment.

Other Taylor Hobson instruments use a stylus with a tip radius of 2 μ m (80 μ in). This smaller radius coupled with an inductive gauge head having low contact force enables analysis of even the smallest surface imperfections.



Amplitude parameters



Ra, Rq, Pa, Pq

I1 - I5 are consecutive and equal sampling lengths (I the sampling length corresponds to filter cut-off length $\lambda_{\text{C}}).$

The evaluation length 'L' is defined as the length of profile used for assessing surface roughness parameters (usually containing several sampling lengths; five consecutive sampling lengths are taken as standard).

Ra is the universally recognised, and most used, international parameter of roughness. It is the arithmetic mean of the absolute departures of the roughness profile from the mean line.


$$Ra = \frac{1}{l} \int_{0}^{l} |z(x)| dx$$

Rq is the rms root-mean-square (rms) value of the departures of the profile from the mean line.

$$Rq = \sqrt{\frac{1}{l} \int_{0}^{l} z^{2}(x) dx}$$


Pa and **Pq** are the corresponding parameters from the primary profile.

Note: Rq is sometimes referred to as RMS.



Rz1max

Rz1max is the largest peak to valley in any sampling length within the evaluation length.




Rv, Rp, Rt, Pv, Pp, Pt,

*Rv is the maximum depth of the profile below the mean line within the sampling length.

***Rp** is the maximum height of the profile above the mean line within the sampling length.

Rt is the maximum peak to valley height of the profile in the evaluation length.

Pv, Pp and **Pt** are the corresponding parameters from the waviness and primary profiles, respectively.



Rsk, Rku

Rsk - Skewness - is the measure of the symmetry of the profile about the mean line. It will distinguish between asymmetrical profiles of the same R_a or R_g .

$$Rsk = \frac{1}{Rq^3} \left[\frac{1}{l} \int_0^l z^3 (x) dx \right]$$

Rku – Kurtosis – is a measure of the sharpness of the surface profile.

$$Rku = \frac{1}{Rq^4} \left[\frac{1}{l} \int_0^l z^4 (x) dx \right]$$

Rsk and Rku are calculated within the sampling length.

* Most parameters are defined over one sample length, however in practice more than one sample length is assessed (usually five) and the mean calculated. This provides a better statistical estimate of the parameter's measured value.

Surface finish fundamentals

The surface of every component has some form of texture which varies according to its structure and the way it has been manufactured. These surfaces can be broken down into three main categories: Roughness, Waviness and Form. In order to control the manufacturing process or predict a component's behaviour during use, it is necessary to quantify surface characteristics by using surface texture parameters.

Surface texture parameters can be separated into three basic types:

Amplitude parameters – Measurement of the vertical characteristics of the surface deviations

Spacing parameters – Measurement of the horizontal characteristics of the surface deviations

Hybrid parameters – Combinations of spacing and amplitude parameters

Sample length – The profile is divided into sample lengths I, which are long enough to include a statistically reliable amount of data. For roughness and waviness analysis, the sample length is equal to the selected cut-off.

Cut-off (Lc) – A cut-off is a filter that uses either electronic or mathematical means to remove or reduce unwanted data in order to look at wavelengths in the region of interest. The sample length is also known as the cut-off length.

Evaluation length – The length in the direction of the X axis used for assessing the profile under evaluation. The evaluation length may contain one or more sample lengths. For the primary profiles the evaluation length is equal to the sample length.

Standards – Where appropriate Taylor Hobson equipment follows procedures as determined in ISO 3274-1996, ISO 4287-1997, ISO 4288-1996, ISO 11 562 and other international standards.

All parameters using either Roughness, Waviness or Primary Profiles conform to the following assumptions:

- T = Type of profile, either R (Roughness) or W (Waviness) or P (Primary)
- n = Parameter suffix, e.g. q, t, p, v, etc.
- N = Number of measured sampling lengths

When a parameter is displayed as Tn (e.g. Rp), then it is assumed that the value has been measured over 5 sampling lengths. If the number of measured sampling lengths is other than 5 sampling lengths, then the parameter shall display this number thus TnN, e.g. Rp2.

Max rule – If a parameter also displays max (e.g. Rz1max) then the measured value shall not be greater than the specified tolerance value. If max is not displayed (e.g. Rp) then 16% of the measured values are allowed to be greater than the specified tolerance value.

See ISO 4288-1996 for more details of the Max and 16% rules.

Recommended cut-off ISO 4288-1996				
Periodic profiles	Non-periodic profiles		Cut-offs	Sampling length/ evaluation length
Spacing distance Sm (mm)	Rz (µm)	Ra (µm)	lc (mm)	lc/L (mm)
>0.013 to 0.04	(0.025) to 0.1	(0.006) to 0.02	0.08	0.08/0.4
>0.04 to 0.13	>0.1 to 0.5	>0.02 to 0.1	0.25	0.25/1.25
>0.13 to 0.4	>0.5 to 10	>0.1 to 2	0.8	0.8/4
>0.4 to 1.3	>10 to 50	>2 to 10	2.5	2.5/12.5
>1.3 to 4	>50 to 200	>10 to 80	8	8/40

Accessories and spares

Portable hybrid solar rechargeable power bank*

Portable power bank for charging the Surtronic Duo on the go. Can be charged by USB, mains AC or sunlight.

Code SC-15





Mini USB charger 5V 1A 110-240 VAC 50/60 Hz with international adapters

Code SC-10




5 Calibration standard

For calibrating and checking the Surtronic Duo instrument.

Code CS-20

Ra 5.81 µm (229 µin)



* Not supplied as standard with Surtronic Duo

All accessories listed above are available for order. Please contact your local Taylor Hobson representative for additional or special requirements.

Ompact portable carry bag

Helps secure the Surtronic Duo and prevent accidental drops especially for applications involving measuring at heights.

Code SA-51





Code SA-55

transportation.

6 Magnetic base*

Lightweight compact base specially designed to allow for measurements in multiple orientations including upside down on metallic surfaces.

Code SA-41



Surtronic[®] product range

Surtronic[®] **S100-series** offers high speed roughness with a large display and simple menu structure. Battery powered and offering total portability with a built-in memory for up to 100 readings.

- Unique stylus lift for total flexibility
- Long traverse length & extended pick-up reach
- Powerful PC software included

Features

Gauge range / resolution	400 μm (0.012 in) / 0.01 μm (0.4 μin)
Accuracy (5 µm diamond tip)	1% of reading + LSD μm

IntraTouch measures roughness, waviness and contour. A low cost, portable system for high level surface texture analysis on the shop floor.

- 50mm (1.97in) traverse with straightness datum
- Automatic calibration over a sphere ensures that radius and form measurements are correct


FeaturesGauge range / resolution16 nm @ 1mm range (0.63 µin @ 0.04 in) / 3 nm @
0.2 mm range (0.12 µin @ 0.008 in)Straightness accuracy0.2 µm over any 20 mm (8 µin over any 0.78 in)



The Surtronic[®] R-50/R-80 is robust enough for the shop floor but accurate for any inspection area, giving a flexible solution for all roundness and form measurements.

- Patented gauge orientation
- Robust enough for 24/7 operation
- Easy-to-use touchscreen software

Features	
Gauge resolution	30 nm (1.18 µin)
Spindle accuracy	±25 nm (0.98 μin)



Surtronic[®] **R-100 Series** builds on the robustness and ease-of-use of the R-50/R-80, offering a higher throughput and improved feature set that includes advanced harmonic analyses and a higher gauge resolution.

- Robust, fast and easy-to-use
- Includes Rapid Centre[™]*
- Throughput 3 parts/minute including set-up

Features	
Gauge resolution	6 nm (0.24 µin)
Spindle accuracy	±25 nm (0.98 μin)





The metrology experts

Taylor Hobson is world renowned as a manufacturer of precision measuring instruments used for inspection in research and production facilities. Our equipment performs at nanometric levels of resolution and accuracy.

To complement our precision manufacturing capability we also offer a host of metrology support services to provide our customers with complete solutions to their measuring needs and total confidence in their results.

www.taylor-hobson.com

Centre of Excellence department

Email: taylor-hobson.cofe@ametek.com +44 (0)116 276 3779 Tel:

- Inspection services measurement of your production parts by skilled technicians using industry leading instruments in accord with ISO standards
- Metrology training practical, hands-on training courses for roundness and surface finish conducted by experienced metrologists
- Operator training on-site instruction will lead to greater proficiency and higher productivity
- UKAS calibration and testing certification for artifacts or instruments in our laboratory or at customer's site



Sales department

Email: taylor-hobson.sales@ametek.com Tel: +44 (0)116 246 2034

- Design engineering special purpose, dedicated metrology systems for demanding applications
- Precision manufacturing contract machining services for high precision applications and industries

Service department

Email: taylor-hobson.service@ametek.com Tel: +44 (0)116 246 2900

 Preventative maintenance – protect your metrology investment with an Amecare support agreement



Copyright[©] 2016 • Taylor Hobson Surtronic Duo_02/2016 AUTHORISED UK DISTRIBUTOR: Spectrum Metrology Ltd Tel: 0116 2766262

E-mail: sales@spectrum-metrology.co.uk www.spectrum-metrology.co.uk

Taylor Hobson UK

(Global Headquarters) PO Box 36, 2 New Star Road Leicester, LE4 9JD, England Tel: +44 (0)116 276 3771 Fax: +44 (0)116 246 0579 taylor-hobson.sales@ametek.com

Taylor Hobson China

taylor-hobson-china.sales@ametek.com.cn

Shanghai Office

Part A1, A4. 2nd Floor, Building No. 1, No. 526 Fute 3rd Road East, Pilot Free Trade Zone, Shanghai, 200131, China Tel: +86 21 5868 5111-110 Fax: +86 21 5866 0969-110

Beijing Office

Western Section, 2nd Floor, Jing Dong Fang Building (B10), No. 10, Jui Xian Quio Road, Chaoyang District, Beijing, 100015, China Tel: +86 10 8526 2111 Fax: +86 10 8526 2141

Chengdu Office

Unit 9-10,10th Floor9/F, Hi-tech Incubation Park, No.26 West Jinyue Road, Chengdu. 610041. China Tel: +86 28 8675 8111 Fax: +86 28 8675 8141

Guangzhou Office

Room 1412, Yi An square, No.33 Six Construction Road, Guangzhou, 510060, China Tel: +86 20 8363 4768 Fax: +86 20 8363 3701

Taylor Hobson France

Rond Point de l'Epine Champs Batiment D, 78990 Elancourt, France Tel: +33 130 68 89 30 Fax: +33 130 68 89 39 taylor-hobson.france@ametek.com

Taylor Hobson Germany

Rudolf-Diesel-Straße 16 D-64331 Weiterstadt, Germany Tel: +49 6150 543 0 Fax: +49 6150 543 1502 taylor-hobson.germany@ametek.com

Taylor Hobson India

1st Floor, Prestige Featherlite Tech Park 148, EPIP II Phase, Whitefield, Bangalore - 560 006, India Tel: +91 18 6026 62468 Fax: +91 80 6782 3232

taylor-hobson.india@ametek.com

Taylor Hobson Italy

Via De Barzi, 20087 Robecco sul Naviglio, Milan, Italy Tel: +39 02 946 93401 Fax: +39 02 946 93450 taylor-hobson.italy@ametek.com

Taylor Hobson Japan

3F Shiba NBF Tower, 1-1-30, Shiba Daimon Minato-ku, Tokyo 105-0012, Japan Tel: +81 36809 2406 Fax: +81 36809 2410 taylor-hobson.japan@ametek.com



Taylor Hobson Korea

#309, 3rd FL, Gyeonggi R&DB Center, 105, Gwanggyo-ro, Yeongtong-gu, Suwon-si, Gyeonggi-do, Korea, 16229 Tel: +82 31 888 5255 Fax: +82 31 888 5228 taylor-hobson.korea@ametek.com

Taylor Hobson Mexico

Acceso III No. 16 Nave 3 Parque Ind. Benito Juarez Queretaro, Qro. Mexico C.P. 76120, Mexico Tel: +52 442 426 4480 Fax: +52 442 295 1987 taylor-hobson.mexico@ametek.com



Taylor Hobson Singapore

AMETEK singapore, 10 Ang Mo Kio Street 65, No. 05-12 Techpoint, Singapore 569059 Tel: +65 6484 2388 Ext 120 Fax: +65 6484 2388 Ext 120 taylor-hobson.singapore@ametek.com

Taylor Hobson Taiwan

10F-5, No.120, Sec. 2, Gongdao Wu Rd., Hsinchu City 30072, Taiwan Tel: +886 3 575 0099 Ext 59 Fax: +886 3 575 0799 taylor-hobson.taiwan@ametek.com

Taylor Hobson USA

1725 Western Drive West Chicago, Illinois 60185, USA Tel: +1 630 621 3099 Fax: +1 630 231 1739 taylor-hobson.usa@ametek.com